

18.6 Data Plane Acceptance Criteria

[Go To Top](#)

[Return to Acceptance Criteria](#)

The [Data Plane](#) satisfies Phase 0 acceptance when any included Data Plane topics follow the approved naming, typing, participation, QoS, validation, and placeholder rules.

Data Plane acceptance requires:

1. Each included Data Plane Topic appears in the Topic Catalogue.
2. Each included Data Plane Topic identifies its purpose, carried [Data Structure Definition](#), publisher [Nodes](#), subscriber Nodes, QoS expectations, validation approach, and relationship to the FX Demo Logical Profile.
3. Placeholder Data Plane Topics are clearly marked as placeholders.
4. Data Plane Topics use approved IDL-derived generated types.
5. Publisher Nodes can create and publish representative messages where the baseline requires message flow.
6. Subscriber Nodes can receive and inspect representative messages where the baseline requires message flow.
7. Data Plane QoS settings match the documented expectations.
8. Data Plane validation [Evidence](#) supports any claims made for the Topic.
9. Data Plane implementation does not carry [Control Plane](#) lifecycle, command, or health messages unless the architecture explicitly defines an exception.
10. Phase 0 Data Plane scope remains consistent with the stated non-goals.

© 2026 Dido Solutions, Inc. and Jackrabbit Consulting, Inc.

From:
<https://wiki.didosolutions.com/> - **Dido Solutions, Inc Wiki**

Permanent link:
<https://wiki.didosolutions.com/fxdemo/05-part/18-acceptance-criteria/18-6-data-plane-acceptance-criteria/start>

Last update: **2026/08/12 16:30**

